

AV RECEIVER

Operating Instructions	GB
Mode d'emploi	FR
Manual de instrucciones	ES

Owner's Record

The model and serial numbers are located on the bottom of the unit. Record the serial number in the space provided below. Refer to these numbers whenever you call upon your Sony dealer regarding this product.

Model No. XAV-AX5000

Serial No._____

To cancel the demonstration (Demo) display, see page 16. For the connection/installation, see page 27.

Pour annuler l'affichage de démonstration (Démo), reportezvous à la page 18.

Pour le raccordement/l'installation, reportez-vous à la page 29.

Para cancelar la pantalla de demostración (Demostración), consulte la página 17.

Para la conexión/instalación, consulte la página 29.



For safety, be sure to install this unit in the dashboard of the car as the rear side of the unit becomes hot during use.

For details, see "Connection/Installation" (page 27).

The nameplate indicating operating voltage, etc., is located on the bottom of the chassis.

The validity of the CE marking is restricted to only those countries where it is legally enforced, mainly in the countries EEA (European Economic Area).

Warning

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

FOR THE CUSTOMERS IN THE USA. NOT APPLICABLE IN CANADA, INCLUDING IN THE PROVINCE OF OUEBEC.

POUR LES CLIENTS AUX ÉTATS-UNIS. NON APPLICABLE AU CANADA, Y COMPRIS LA PROVINCE DE OUÉBEC.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

This device complies with Part 15 of the FCC Rules and Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

(1) This device may not cause interference; and (2) This device must accept any interference, including Interference that may cause undesired operation of the device.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that is deemed to comply without maximum permissive exposure evaluation (MPE).

For the State of California, USA only

Perchlorate Material – special handling may apply, See

www.dtsc.ca.gov/hazardouswaste/perchlorate

WARNING: Do not ingest battery, Chemical Burn Hazard.

The remote commander contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.

Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children.

If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

Note on the lithium battery

Do not expose the battery to excessive heat such as direct sunlight, fire or the like.

Warning if your car's ignition has no ACC position

Do not install this unit in a car that has no ACC position. The display of the unit does not turn off even after turning the ignition off, and this causes battery drain.

Disclaimer regarding services offered by third parties

Services offered by third parties may be changed, suspended, or terminated without prior notice. Sony does not bear any responsibility in these sorts of situations.

Important notice

Caution

IN NO EVENT SHALL SONY BE LIABLE FOR ANY INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGES OR OTHER DAMAGES INCLUDING, WITHOUT LIMITATION, LOSS OF PROFITS, LOSS OF REVENUE, LOSS OF DATA, LOSS OF USE OF THE PRODUCT OR ANY ASSOCIATED EQUIPMENT, DOWNTIME, AND PURCHASER'S TIME RELATED TO OR ARISING OUT OF THE USE OF THIS PRODUCT, ITS HARDWARE AND/OR ITS SOFTWARE.

Dear customer, this product includes a radio transmitter.

Please check your vehicle operation manual or contact the manufacturer of your vehicle or your vehicle dealer, before you install this product into your vehicle.

Emergency calls

This BLUETOOTH car handsfree and the electronic device connected to the handsfree operate using radio signals, cellular, and landline networks as well as user-programmed function, which cannot guarantee connection under all conditions. Therefore do not rely solely upon any electronic device for essential communications (such as medical emergencies).

On BLUETOOTH communication

- Microwaves emitting from a BLUETOOTH device may affect the operation of electronic medical devices. Turn off this unit and other BLUETOOTH devices in the following locations, as it may cause an accident.
- where inflammable gas is present, in a hospital, train, airplane, or petrol station
- near automatic doors or a fire alarm
- This unit supports security capabilities that comply with the BLUETOOTH standard to provide a secure connection when the BLUETOOTH wireless technology is used, but security may not be enough depending on the setting. Be careful when communicating using BLUETOOTH wireless technology.
- We do not take any responsibility for the leakage of information during BLUETOOTH communication.


If you have any questions or problems concerning your unit that are not covered in this manual, consult your nearest Sony dealer.

Table of Contents
Warning
Getting Started
Performing Initial Settings 8
Preparing a BLUETOOTH Device 8
Connecting Rear View Camera
Listening to the Radio
Listening to the Radio 9
Using Tuner Option Functions
Listening to the SiriusXM Radio 10
Using SXM Option Functions
Playback
Playing a USB Device
Playing a BLUETOOTH Device
Searching and Playing Tracks
Other Settings During Playback
Handsfree Calling
Receiving a Call
Making a Call
Available Operations During a Call
Useful Functions
Apple CarPlay
Android Auto $^{\text{\scriptsize IM}}$
Using Gesture Command
Settings
Basic Setting Operation
General Settings (General)
Sound Settings (Sound)
Visual Settings (Visual)
BLUETOOTH Settings (Bluetooth)
Additional Information
Updating the Firmware
Precautions
Maintenance
Specifications
Troubleshooting
Messages

Connection/Installation	
Cautions	27
Parts List for Installation	27
Connection	28
Installation	30

Guide to Parts and Controls

Main unit



The VOL (volume) + button has a tactile dot.

- 1 Display/touch panel
- 2 HOME

Open the HOME menu.

■ ATT (attenuate)

Press and hold for 1 second to attenuate the sound

To cancel, press and hold again, or press VOL +.

- 3 VOL (volume) +/-
- 4 Receptor for the remote commander

5 I◀◀ /▶▶I (previous/next)

- Move to the previous/next item.
- Press and hold to fast-reverse/fast-forward.

6 OPTION


Press to open the OPTION screen (page 7).

■ VOICE

Press and hold to activate the voice command function for Apple CarPlay and Android Auto.

RM-X170 remote commander

The remote commander can be used to operate the audio controls. For menu operations, use the touch panel.



Note

The white buttons in the illustration above are not supported.

7 OFF

Turn the source off.

8 MONITOR OFF

Turn off the monitor. To turn back on, press again.

9 EQ (equalizer)

Select an equalizer curve.

10 Number buttons (0 - 9)

11 CLEAR

12 ►II (play/pause)

13 I◀◀ /▶►I (previous/next)

◄ (fast-reverse/fast-forward)

14 ←/**↑**/**↓**/→

Functions differ depending on the selected source.

- Tuner: select a preset station or tune into a station automatically.
- SiriusXM: select a preset channel or move to the previous/next channel.
- USB: select a folder or move to the previous/ next file.

ENTER

Enter the selected item.

15 SRC (source)

Change the source. Each time you press this button, a selectable source is displayed in a popup on the current display.

16 MODE


Select the radio band.

Remove the insulation film before use.




Screen displays


Playback screen:



HOME screen:



OPTION screen:



Status indication

■ ATT Lights up when the sound is attenuated.

SXM.il Indicates the signal strength status of the connected SiriusXM Connect Vehicle Tuner.

Lights up when the audio device is playable by enabling the A2DP (Advanced Audio Distribution Profile).

Lights up when handsfree calling is available by enabling the HFP (Handsfree Profile).

Indicates the signal strength status of the connected cellular phone.

Indicates the remaining battery status of the connected cellular phone.

Uights up when the Bluetooth® signal is on. Flashes when the connection is in progress.

2 ··· (source option)

Open the source option menu. The available items differ depending on the source.

3 Application specific area

Display playback controls/indications or show the unit's status. Displayed items differ depending on the source.

4 Clock (page 16)

5 (return to the playback screen)

Switch from the HOME screen to the playback screen.

6 Sources and Settings select keys

Change the source or make various settings.

7 Sources select keys

Change the source.

8 EXTRA (EXTRA BASS)
Change the EXTRA BASS setting (page 17).

9 ‡†‡ (EQ10/Subwoofer)

Change the EQ10/Subwoofer setting (page 17).

(monitor off)

Turn off the monitor. When the monitor is turned off, touch any part of the display to turn it back on.

Getting Started

Performing Initial Settings

You need to perform initial settings before operating the unit for the first time, after replacing the car battery, or changing connections. If the initial settings screen does not appear when you turn on the unit, perform the factory reset (page 17) to initialize the unit.

- Touch [Language], then set the display language.
- 2 Touch [Demo] repeatedly to select [OFF] to disable the demonstration mode.
- 3 Touch [Set Date/Time], then set the date and time.
- 4 After setting the date and time, touch [OK].
- 5 To return to the previous display, touch \$\frac{1}{2}\$, then touch [OK].

The startup caution appears.

6 Read through the startup caution, then if you accept all conditions, touch [Close]. The setting is complete.

This setting can be further configured in the setting menu (page 16).

Preparing a BLUETOOTH Device

You can enjoy music or perform handsfree calling depending on the BLUETOOTH compatible device such as smartphones, cellular phones, and audio devices (hereafter "BLUETOOTH device" if not otherwise specified). For details on connecting, refer to the operating instructions supplied with the device.

Before connecting the device, turn down the volume of this unit; otherwise, a loud sound may result.

Pairing and connecting with a BLUETOOTH device

When connecting a BLUETOOTH device for the first time, mutual registration (called "pairing") is required. Pairing enables this unit and other devices to recognize each other.



- Place the BLUETOOTH device within 1 m (3 ft) of this unit.
- 2 Press HOME, then touch [Settings].
- 3 Touch [Bluetooth].
- 4 Touch [Bluetooth Connection], then set the signal to [ON].


The BLUETOOTH signal is turned on and 3 lights up on the status bar of the unit.

- 5 Touch [Pairing].
 - § flashes while the unit is in pairing standby mode.
- **6** Perform pairing on the BLUETOOTH device so it detects this unit.
- 7 Select [XAV-AX5000] shown in the display of the BLUETOOTH device.

If your model name does not appear, repeat from step 5.



- 8 If passkey* input is required on the BLUETOOTH device, input [0000].
 - * Passkey may be called "passcode," "PIN code," "PIN number," "password," etc., depending on the BLUETOOTH device.



When pairing is made, 3 stays lit.

9 Select this unit on the BLUETOOTH device to establish the BLUETOOTH connection.

Notes

- The unit can only be connected with one BLUETOOTH device at a time.
- To disconnect the BLUETOOTH connection, turn the connection off from either the unit or the BLUETOOTH device.
- BLUETOOTH pairing is not possible while Apple CarPlay or Android Auto is running.

Connecting with a paired BLUETOOTH device

To use a paired device, connection with this unit is required. Some paired devices will connect automatically.



- 1 Press HOME, then touch [Settings].
- 2 Touch [Bluetooth].
- 3 Touch [Bluetooth Connection], then touch [ON].

Make sure that **3** lights up on the status bar of the unit.

- 4 Activate the BLUETOOTH function on the BLUETOOTH device.
- 5 Operate the BLUETOOTH device to connect to this unit.

or polights up on the status bar.

To connect the last-connected device from this unit

When the ignition is turned to on with the BLUETOOTH signal activated, this unit searches for the last-connected BLUETOOTH device, and connection is made automatically.

Note

While streaming BLUETOOTH audio, you cannot connect from this unit to the cellular phone. Connect from the cellular phone to this unit instead.

To install the microphone

For details, see "Installing the microphone" (page 29).

Connecting Rear View Camera

By connecting the optional rear view camera to the CAMERA IN terminal, you can display the picture from the rear view camera. For details, see "Connection/Installation" (page 27).

To display the picture from the rear view camera


Press HOME, touch [Rear Camera].

Listening to the Radio

Listening to the Radio

To listen to the radio, press HOME then touch [Tuner].

Reception controls/indications



Current band

Change the band (FM1, FM2, FM3, AM1 or AM2).

- © Current frequency, program service name*, RDS (Radio Data System) indication*
 - * During RDS reception.
- **⊙** ··· (tuner option)

Open the tuner option menu.

SEEK-/SEEK+

Tune in automatically.

B </>

Tune in manually.
Touch and hold to continuously skip frequencies.

Preset numbers

Select a preset station. Swipe right/left to show the other preset stations.

Touch and hold to store the current frequency in that preset.

Tuning

- Select the desired band (FM1, FM2, FM3, AM1 or AM2).
- 2 Perform tuning.

To tune automatically

Touch SEEK-/SEEK+.

Scanning stops when the unit receives a station.

To tune manually

Touch and hold $\langle \rangle$ to locate the approximate frequency, then touch $\langle \rangle$ repeatedly to fine adjust to the desired frequency.

Storing manually

 While receiving the station that you want to store, touch and hold the desired preset number.

Receiving stored stations

Select the band, then touch the desired preset number.

Using Tuner Option Functions

The following functions are available by touching

BTM (Best Tuning Memory)

Stores stations in order of frequency on the preset numbers. 18 stations can be stored for FM and 12 stations for AM as preset stations.

PTY*

Select a program type from the PTY list to search for a station broadcasting the selected program type.

* Only available during FM reception.

Listening to the SiriusXM Radio

To listen to the SiriusXM radio, press HOME then touch [SXM].

Activating your SiriusXM Subscription

Only SiriusXM brings you more of what you love to listen to, all in one place. Get over 140 channels, including commercial-free music plus the best sports, news, talk, comedy and entertainment. Welcome to the world of satellite radio. A SiriusXM Connect Vehicle Tuner and Subscription are required. For more information, visit www.siriusxm.com

After installing your SiriusXM Connect Vehicle Tuner and antenna (aerial), press HOME, then touch [SXM]. You should be able to hear the SiriusXM preview channel on Channel 1. After verifying that you can hear the preview channel, select Channel 0 to find the Radio ID of your tuner. In addition, the Radio ID is located on the bottom of the SiriusXM Connect Vehicle Tuner and its packaging. You will need this number to activate your subscription. Write the number down for reference.

Note

 The SiriusXM Radio ID does not include the letters I, O, S or F. In the USA, you can activate online or by calling SiriusXM Listener Care:

Online: Visit www.siriusxm.com/activatenow

Phone: Call 1-866-635-2349

In Canada, you can activate online or by calling SiriusXM Listener Care:

Online: Visit www.siriusxm.ca/activatexm

• Phone: Call 1-877-438-9677


As part of the activation process, the SiriusXM satellites will send an activation message to your tuner. When your radio detects that the tuner has received the activation message, your radio will display: [Subscription Updated Press Enter to Continue]. Once subscribed, you can tune to channels in your subscription plan.


Notes

- The activation process usually takes 10 to 15 minutes, but may take up to an hour.
- Your radio will need to be turned on and receiving the SiriusXM signal to receive the activation message.

Tuning channels for SiriusXM

Reception controls/indications





- ♠ I (list)
 Open the channel list or category list.
- GH- (previous channel) /CH+ (next channel) Select the channel.
- Channel number, channel name, artist name, song title
- (information)
 Switch the channel information.
- (SXM option)
 Open the SXM option menu.
- Preset numbers

Select a preset channel. Swipe right/left to show the other preset channels. Touch and hold to store the current channel in that preset.

G Channel number, channel name, category name, content information

To tune the channel from the channel list or category list

- 1 Touch : ■.
- 2 Touch [Channel List]. Alternatively, touch [Category List], then touch the desired category item.

The channel list appears.

3 Touch the desired channel.

To store channels

1 While receiving the channel that you want to store, touch and hold a number key (1 to 6).

To receive the stored channel, touch a number key (1 to 6).

To set a parental control

The parental control feature allows you to limit access to SiriusXM channels with mature content. When enabled, the parental control feature requires you to enter a passcode to tune to the locked channels. Information on setting up the passcode and locking channels can be found below.

- 1 Touch •••, then touch [Parental Control]. The passcode input display appears.
- 2 Enter your 4-digit passcode by touching the number keys, then touch [OK].
 The passcode confirmation display appears.
- 3 Enter the 4-digit passcode again, then touch [OK]. The parental control is applied, and the channels are locked.

To unlock the channels/To lock the channels again

- 1 Touch •••, then touch [Parental Control]. The passcode input display appears.
- 2 Enter your 4-digit passcode by touching the number keys, then touch [OK].

To change the passcode

- 1 Touch •••, touch [Pass Code Change], then enter your current passcode.
- 2 Enter your new passcode.

Using SXM Option Functions

The following functions are available by touching ••••.

Parental Control

Set the parental lock to on or off, and edit the passcode.

Pass Code Change

Change the passcode for the Parental Control feature.

Playback

Playing a USB Device

MSC (Mass Storage Class) type USB devices*1 compliant with the USB standard can be used. MTP (Media Transfer Protocol) type USB devices*1*2 can be used only when connected to the USB2 port.

- *1 e.g., a USB flash drive, digital media player, Android™ phone
- *2 Some digital media players or Android phones may require setting to MTP mode.

Notes

- For details on the compatibility of your USB device, visit the support site on the back cover.
- For details on the supported file formats, see "Supported formats for USB playback" (page 19).
- Turn down the volume on the unit.
- 2 Connect the USB device to the USB port.
- 3 Press HOME, then touch [USB1] or [USB2]. Playback starts.

To remove the device

Turn the unit off or turn the ignition switch to the ACC off position, then remove the USB device.

USB1 port and USB2 port

When connecting the USB devices, select the USB1 port or the USB2 port according to the features to be used.

Supported features		USB1	USB2
Apple CarPlay		1	-
Android Auto		1	-
	FAT12	1	1
File system	FAT16	1	1
File system	FAT32	1	1
	exFAT	1	-
	MP3	1	1
	WMA	1	✓
Playable audio format	FLAC	1	1
	WAV	1	-
	AAC	1	-

Supported features		USB1	USB2
	MPEG-4	1	-
Playable video	WMV	1	-
format	MKV	1	-
	Xvid	1	-
USB connection	MSC	1	1
mode	MTP	-	1

✓: Available, –: Not supported

Playing a BLUETOOTH Device

You can play contents on a connected device that supports BLUETOOTH A2DP (Advanced Audio Distribution Profile).



- 1 Make a BLUETOOTH connection with the audio device (page 9).
- 2 Press HOME, then touch [BT Audio].
- 3 Operate the audio device to start playback.

Notes

- Depending on the audio device, information such as title, track number/time, and playback status may not be displayed on this unit.
- Even if the source is changed on this unit, playback of the audio device does not stop.
- BLUETOOTH pairing is not possible while Apple CarPlay is running.

To match the volume level of the BLUETOOTH device to other sources

You can reduce the volume level differences between this unit and the BLUETOOTH device: During playback, touch •••, then set [Input Level] between –6 and +6.

Searching and Playing Tracks

Repeat play and shuffle play

1 During playback, touch (repeat) or (shuffle) repeatedly until the desired play mode appears.

Playback in the selected play mode may take time to start.

Available play modes differ depending on the selected sound source and connected device.

Searching for a file from the list screen

During USB playback, touch : ■.
 The list screen from the currently played item appears.



Furthermore, touch **[1]** (audio) or **[1]** (video) to list up by file type.

2 Touch the desired item. Playback starts.

Other Settings During Playback

Further settings are available in each source by touching •••. The available items differ depending on the source.

Picture EO

Adjusts the picture quality according to your taste: [Dynamic], [Standard], [Theater], [Custom]. (Available only when the parking brake is applied and USB video is selected).

Aspect

Selects an aspect ratio for the screen of the unit. (Available only when the parking brake is applied and USB video is selected).

Normal

Displays a 4:3 picture in its original size, with side bars to fill the 16:9 screen.

Zoom

Displays a 16:9 picture that has been converted into 4:3 letter box format.

Full

Displays a 16:9 picture in its original size.

Captions

Enlarges the picture horizontally, while fitting captions in the screen.

Handsfree Calling

To use a cellular phone, connect it with this unit. For details, see "Preparing a BLUETOOTH Device" (page 8).



Note

The handsfree calling functions explained below are available only when the Apple CarPlay or Android Auto function is deactivated. When the Apple CarPlay or Android Auto function is activated, use the handsfree calling functions on its application.

Receiving a Call

1 Touch when a call is received. The phone call starts.


Note

The ringtone and talker's voice are output only from the front speakers.

To reject/end a call Touch .

Making a Call

- 1 Press HOME, then touch [Phone].
- 2 Touch one of the call icons on the BLUETOOTH phone display.



- ♠ \$\(\) (call history)*
 Select a contact from the call history list. The unit stores the last 20 calls.
- Make a call automatically to the last contact you made.

Select a contact from the name list/number list in the phonebook. To search for the desired contact in alphabetical order from the name list, touch Q.

- (phone number input) Enter the phone number.
- Preset phone number list
 Select the stored contact.
 To store the contact, see "Presetting phone numbers" (page 14).
- * The cellular phone needs to support PBAP (Phone Book Access Profile).
- **3** Touch **?**. The phone call starts.

Presetting phone numbers

You can store up to 6 contacts in the preset list.

- In the phone screen, select a phone number that you want to store in the preset dial from the phonebook.
- The confirmation display appears.

 2 Touch [Add to Preset].
- 3 Select the preset phone number list where the phone number is stored.

The contact is stored in the preset phone number list.

Available Operations During a Call

To adjust the ringtone volume

Press VOL +/- while receiving a call.

To adjust the talker's voice volume Press VOL +/- during a call.

To adjust the volume for the other party (Mic gain adjustment)

During a handsfree call, touch •••, then set [MIC Gain] to [High], [Middle], or [Low].

To reduce echo and noise (Echo/noise canceler mode)

During a call, touch •••, then set [Speech Quality] to [Mode 1] or [Mode 2].

To switch between handsfree mode and handheld mode

During a call, touch $\P o \P$ to switch the phone call audio between the unit and cellular phone.

Note

Depending on the cellular phone, this operation may not be available

To answer an incoming call automatically Touch •••, then set [Auto Answer] to [ON].

Useful Functions

Apple CarPlay

Apple CarPlay lets you use your iPhone in the car in a way that allows you to stay focused on the road. (Available only when your iPhone is connected to the USB1 port.)

Notes on using Apple CarPlay

- iPhone with iOS 7.1 or later is required. Update to the latest iOS version before use.
- Apple CarPlay can be used on iPhone 5 or later.
- For details on compatible models, refer to the compatibility list on the support site on the back cover
- For details about Apple CarPlay, refer to the manual supplied with your iPhone, or visit the website of Apple CarPlay.
- Since the GPS on your iPhone is used, place your iPhone where it can easily receive a GPS signal.
- 1 Connect your iPhone to the USB1 port. To connect an iPhone, use a USB connection cable for iPhone (not supplied).
- 2 Press HOME, then touch the Apple CarPlay icon.

Your iPhone's display appears on the display of the unit. Touch and control the applications.

Use of the Apple CarPlay logo means that a vehicle user interface meets Apple performance standards. Apple is not responsible for the operation of this vehicle or its compliance with safety and regulatory standards.

Please note that the use of this product with iPhone may affect wireless performance.

Android Auto™

Android Auto extends the Android platform into the car in a way that's purpose-built for driving. (Available only when your Android phone is connected to the USB1 port.)

Notes on using Android Auto

- Android phone with Android 5.0 or higher is required. Update to the latest OS version before use.
- Your Android phone needs to support Android Auto. For details on compatible models, refer to the compatibility list on the support site on the back cover.
- Download the Android Auto app on Google Play.
- For details about Android Auto, refer to the manual supplied with your Android phone, or visit the website of Android Auto.

- Since the GPS on your Android phone is used, place your Android phone where it can easily receive a GPS signal.
- Android Auto may not be available in your country or region.
- Connect your Android phone to the USB1 port.

To connect an Android phone, use an appropriate connection cable (not supplied).

2 Press HOME, then touch the Android Auto icon.

The Android Auto interface will be displayed fullscreen on the display of the unit. Touch and control the applications.

Using Gesture Command

You can perform frequently-used operations by swiping your finger on the reception/playback display.

Note

The gesture commands explained below are not available on the screens of Apple CarPlay and Android Auto.

Do this	То		
Swipe left to right	Radio reception: seek forward stations. (The same as pressing and holding ▶►1.) SiriusXM reception: tune the next channel (channel +).		
	Video/audio playback: skip forward a file/track. (The same as ►►1.)		
Swipe right to left	Radio reception: seek backward stations. (The same as pressing and holding Id=1.) SiriusXM reception: tune the previous channel (channel -).		
	Video/audio playback: skip backward a file/track. (The same as ◄◄.)		
Swipe upwards	Radio reception: receive stored stations (go forward). SiriusXM reception: tune the next preset (preset +).		
Swipe downwards	Radio reception: receive stored stations (go backward). SiriusXM reception: tune the previous preset (preset –).		

Settings

Basic Setting Operation

You can set items in the following setup categories: General Settings (General), Sound Settings (Sound), Visual Settings (Visual), BLUETOOTH Settings (Bluetooth)

- 1 Press HOME, then touch [Settings].
- 2 Touch one of the setup category. The items that can be set differ depending on the source and settings.
- 3 Move the scrollbar up and down to select the desired item.

To return to the previous display Touch .

To switch to the playback screen Touch □₅.

General Settings (General)

Language

Selects the display language: [English], [Español], [Français], [Deutsch], [Italiano], [Português], [Русский], [খրв], [희休中文], [繁體中文], [한국어].

Demo

Activates the demonstration: [OFF], [ON].

Date/Time

Date Format

Selects the format: [DD/MM/YY], [MM/DD/YY], [YY/MM/DD].
Time Format

Time Format

Selects the format: [12-hour], [24-hour].

Set Date/Time

Sets the date and clock time manually.

Beep

Activates the operation sound: [OFF], [ON].

Rear View Camera

Selects the image from the rear view camera: [OFF], [Normal], [Reverse] (mirror image). [Guide Line Adjust] adjusts the guide on the picture from the rear view camera.

Touch the near side **(A)** or far side **(B)** (red portions) of the guide to adjust.

Touch </∧/ >/∨ to adjust the guide position, and touch



 $[\rightarrow\leftarrow]$ or $[\leftarrow\rightarrow]$ to adjust the guide width.

Steering Control

Selects the input mode for the connected remote control. To prevent a malfunction, be sure to match the input mode with the connected remote control before use.

Custom

Input mode for the steering wheel remote control (follow the procedures of [②] to register functions on the connected remote control).

Input mode for the wired remote control excluding the steering wheel remote control.

0

The steering button panel appears.

- Press and hold the button you want to assign to the steering wheel.
- The button on the panel lights up (standby).

 Press and hold the button on the steering wheel you want to assign the function to.
 The button on the panel will change the color (highlighted or encircled by an orange line).
- 3 To register other functions, repeat steps 1 and 2.

(Available only when [Steering Control] is set to [Custom].)

Notes

- While making settings, the connected remote control cannot be used even though some functions have already been registered. Use the buttons on the unit.
- If an error occurs while registering, all the registered information is cleared. Restart registration from the beginning.
- This function may not be available on some vehicles.
 For details on the compatibility of your vehicle, visit the support site on the back cover.

Clock Time

Sets the clock time by the RDS data: [OFF], [ON].

SXM Reset

Initializes the SiriusXM Connect Vehicle Tuner settings (preset channels/parental lock): [Reset], [Cancel].

Factory Reset

Initializes all the settings to the factory settings.

Firmware Version

Updates and confirms the firmware version.

Open Source Licenses

Displays the software licenses.

Sound Settings (Sound)

EXTRA BASS

Reinforces bass sound in synchronization with the volume level: [OFF], [1], [2].

EQ10/Subwoofer

Selects an equalizer curve and adjusts the subwoofer level.

EQ10

Selects the equalizer curve: [OFF], [R&B], [Rock], [Pop], [Dance], [Hip-Hop], [EDM], [Jazz], [Soul], [Country], [Custom].

[Custom] adjusts the equalizer curve: –6 to +6. Subwoofer

Adjusts the volume level of the subwoofer: [OFF], –10 to +10.

Balance/Fader

Adjusts the balance/fader level.

Balance

Adjusts the sound balance between the left and right speakers: [L15] to [R15].

Fader

Adjusts the sound balance between the front and rear speakers: [Front 15] to [Rear 15].

Crossover

Adjusts the cut-off frequency and subwoofer phase.

High Pass Filter

Selects the cut-off frequency of the front/rear speakers: [OFF], [50Hz], [60Hz], [80Hz], [100Hz], [120Hz].

Low Pass Filter

Selects the cut-off frequency of the subwoofer: [OFF], [50Hz], [60Hz], [80Hz], [100Hz], [120Hz].

Subwoofer Phase

Selects the subwoofer phase: [Normal], [Reverse].

DSO (Dynamic Stage Organizer)

Enhances audio output: [OFF], [Low], [Middle], [High].

Visual Settings (Visual)

Wallpaper

Changes the wallpaper by touching the desired color.

Dimmer

Dims the display: [OFF], [Auto], [ON]. ([Auto] is available only when the illumination control lead is connected and works when the head light is turned on.)

[] adjusts the brightness level when the dimmer is activated: -5 to +5.

BLUETOOTH Settings (Bluetooth)

Bluetooth Connection

Activates the BLUETOOTH signal: [OFF], [ON], [Pairing] (enters into pairing standby mode).

Bluetooth Device Info

Displays the information of the device connected to the unit.

(Available only when [Bluetooth Connection] is set to [ON] and a BLUETOOTH device is connected to the unit.)

Bluetooth Reset

Initializes all BLUETOOTH-related settings such as pairing information, call history, history of connected BLUETOOTH devices, etc.

Additional Information

Updating the Firmware

To update the firmware, visit the support site on the back cover, then follow the online instructions.

Note

During the update, do not remove the USB device.

Precautions

- · Power antenna (aerial) extends automatically.
- When you transfer ownership or dispose of your car with the unit installed, initialize all the settings to the factory settings by performing the factory reset (page 17).
- . Do not splash liquid onto the unit.

Notes on safety

- Comply with your local traffic rules, laws, and regulations.
- While driving
- Do not watch or operate the unit, as it may lead to distraction and cause an accident. Park your car in a safe place to watch or operate the unit.
- Do not use the setup feature or any other function which could divert your attention from the road.
- When backing up your car, be sure to look back and watch the surroundings carefully for your safety even if the rear view camera is connected.
 Do not depend on the rear view camera exclusively.
- · While operating
- Do not insert your hands, fingers, or foreign objects into the unit as it may cause injury or damage to the unit.
- Keep small articles out of the reach of children.
- Be sure to fasten seatbelts to avoid injury in the event of sudden movement of the car.

Preventing an accident

Pictures appear only after you park the car and set the parking brake.

If the car starts moving during video playback, the following caution is displayed and you cannot watch the video.

[Video blocked for your safety.]

Do not operate the unit or watch the monitor while driving.

Notes on LCD panel

• Do not get the LCD panel wet or expose it to liquids. This may cause a malfunction.



- Do not press down hard on the LCD panel as doing so can distort the picture or cause a malfunction (i.e., the picture may become unclear or the LCD panel may be damaged).
- Do not touch the panel with objects other than with your finger as it may damage or break the LCD panel.
- Clean the LCD panel with a dry soft cloth. Do not use solvents such as benzine, thinner, commercially available cleaners, or antistatic spray.
- Do not use the unit outside the temperature range $0 \, ^{\circ}\text{C} 40 \, ^{\circ}\text{C}$ (32 $^{\circ}\text{F} 104 \, ^{\circ}\text{F}$).
- If your car was parked in a cold or hot place, the picture may not be clear. However, the monitor is not damaged and the picture will become clear after the temperature in your car becomes normal.
- •Some stationary blue, red, or green dots may appear on the monitor. These are called "bright spots" and can happen with any LCD. The LCD panel is precision-manufactured with more than 99.9% of its segments functional. However, it is possible that a small percentage (typically 0.01%) of the segments may not light up properly. This will not, however, interfere with your viewing.

Notes on the touch panel

- This unit uses a capacitive touch panel. Touch the panel directly with your fingertip.
- Multi-touch operation is not supported on this unit.
- Do not touch the panel with sharp objects such as a needle, pen, or fingernail. Operation with a stylus is not supported on this unit.
- Touching the panel with a gloved finger may cause the unit to operate incorrectly or not respond.
- Do not let any objects contact the touch panel. If the panel is touched by an object other than your fingertip, the unit may not respond correctly.
- Since glass material is used for the panel, do not subject the unit to strong shock. If cracking or chipping occurs on the panel, do not touch the damaged part as it may cause injury.
- Keep other electrical devices away from the touch panel. They may cause the touch panel to malfunction.
- If there are water droplets on the touch panel, or if you touch the panel with wet fingertips, the touch panel may not react correctly.

Supported formats for USB playback

USB1 port:

- WMA (.wma)*1*2

Bit rate: 48 kbps – 192 kbps (Supports variable bit rate (VBR))*3

Sampling frequency*4: 44.1 kHz

- MP3 (.mp3)*1*2

Bit rate: 48 kbps – 320 kbps (Supports variable bit rate (VBR))*3

Sampling frequency*4: 32 kHz, 44.1 kHz, 48 kHz

AAC (.m4a)*1*2
 Bit rate: 40 kbps – 320 kbps (Supports variable bit rate (VBR))*3

Sampling frequency*4: 8 kHz – 48 kHz Bit per sample (Quantization bit): 16 bits

FLAC (.flac)*1*6
 Sampling frequency*4: 8 kHz – 48 kHz
 Bit per sample (Quantization bit): 16 bits

WAV (.wav)*1
 Sampling frequency*4: 8 kHz – 48 kHz
 Bit per sample (Quantization bit): 16 bits, 24 bits

Xvid (.avi)

Video codec: MPEG-4 Advanced Simple Profile

Audio codec: MP3 (MPEG-1 Layer3) Bit rate: Max. 4 Mbps

Frame rate: Max. 30 fps (30p/60i) Resolution: Max. 1280 × 720*5

MPEG-4 (.mp4)

Video codec: MPEG-4 Advanced Simple Profile,

AVC Baseline Profile Audio codec: AAC Bit rate: Max. 4 Mbps

Frame rate: Max. 30 fps (30p/60i) Resolution: Max. 1280 × 720*5

WMV (.wmv, .avi)*1
 Video codec: WMV3, WVC1
 Audio codec: MP3, WMA
 Bit rate: Max. 6 Mbps

Frame rate: Max. 30 fps Resolution: Max. 720 × 480*5

- MKV (.mkv)

Video codec: MPEG-4 Advanced Simple Profile,

AVC Baseline Profile Audio codec: MP3, AAC Bit rate: Max. 5 Mbps Frame rate: Max. 30 fps Resolution: Max. 1280 × 720*5

USB2 port:

WMA (.wma)*1*2

Bit rate: 48 kbps - 192 kbps (Supports variable bit rate (VBR))*3

Sampling frequency*4: 44.1 kHz

MP3 (.mp3)*1*2
 Bit rate: 48 kbps – 320 kbps (Supports variable bit rate (VBR))*3

Sampling frequency*4: 32 kHz, 44.1 kHz, 48 kHz

- FLAC (.flac)*1

Sampling frequency*4: 8 kHz – 48 kHz Bit per sample (Quantization bit): 8 bits, 16 bits, 24 bits

- *1 Copyright-protected files and multi-channel audio files cannot be played back.
- *2 DRM (Digital Rights Management) files cannot be played back.
- *3 Non-standard bit rates or non-guaranteed bit rates are included depending on the sampling frequency.
- *4 Sampling frequency may not correspond to all encoders.
- *5 These numbers indicate the maximum resolution of playable video and do not indicate the player's display resolution. The display resolution is 800 × 480.
- *6 Displaying the tag information is not supported.

Note

Some files may not be played back even though their file formats are supported by the unit.

About iPhone

- For details on compatible iPhone models, visit the support site on the back cover.
- Use of the Made for Apple badge means that an accessory
 has been designed to connect specifically to the Apple
 product(s) identified in the badge, and has been certified
 by the developer to meet Apple performance standards.
 Apple is not responsible for the operation of this device or
 its compliance with safety and regulatory standards.
 Please note that the use of this accessory with an Apple
 product may affect wireless performance.

Notice on license

This product contains software that Sony uses under a licensing agreement with the owner of its copyright. We are obligated to announce the contents of the agreement to customers under requirement by the owner of copyright for the software.

For details on software licenses, see page 17.

Notice on GNU GPL/LGPL applied software

This product contains software that is subject to the following GNU General Public License (hereinafter referred to as "GPL") or GNU Lesser General Public License (hereinafter referred to as "LGPL"). These establish that customers have the right to acquire, modify, and redistribute the source code of said software in accordance with the terms of the GPL or LGPL displayed on this unit. The source code for the above-listed software is available on the Web.

To download, please access the following URL then select the model name "XAV-AX5000."

URL: http://www.sony.net/Products/Linux/ Please note that Sony cannot answer or respond to any inquiries regarding the content of the source code.

If you have any questions or problems concerning your unit that are not covered in this Operating Instructions, consult your nearest Sony dealer.


Maintenance

Replacing the lithium battery (CR2025) of the remote commander

When the battery becomes weak, the range of the remote commander becomes shorter.

CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.



Note on the lithium battery

Keep the lithium battery out of the reach of children. Should the battery be swallowed, immediately consult a doctor.

Specifications

FOR THE CUSTOMERS IN THE USA. NOT APPLICABLE IN CANADA, INCLUDING IN THE PROVINCE OF OUEBEC.

POUR LES CLIENTS AUX ÉTATS-UNIS. NON APPLICABLE AU CANADA, Y COMPRIS LA PROVINCE DE QUÉBEC.

AUDIO POWER SPECIFICATIONS



CTA2006 Standard Power Output: 20 Watts RMS × 4 at 4 Ohms < 1% THD+N

SN Ratio: 80 dBA (reference: 1 Watt into

4 Ohms)

Monitor section

Display type: Wide LCD color monitor

Dimensions: 6.95 in System: TFT active matrix Number of pixels:

1,152,000 pixels (800 × 3 (RGB) × 480)

Color system:

PAL/NTSC automatic select for CAMERA IN

terminal

Tuner section

FΜ

Tuning range: 87.5 MHz - 107.9 MHz

Usable sensitivity: 7 dBf

Signal-to-noise ratio: 70 dB (mono)

Separation at 1 kHz: 45 dB

ΑM

Tuning range: 530 kHz - 1,710 kHz

Sensitivity: 32 µV

USB player section

Interface:

USB1 port: USB (Hi-speed)
USB2 port: USB (Full-speed)

Maximum current: USB1 port: 1.5 A USB2 port: 500 mA

Wireless communication

Communication System:

BLUETOOTH Standard version 3.0

Output:

BLUETOOTH Standard Power Class 2 (Max. +4 dBm)

Maximum communication range*1:

Line of sight approx. 10 m (33 ft)

Frequency band:

2.4 GHz band (2.4000 GHz - 2.4835 GHz)

Modulation method: FHSS

Compatible BLUETOOTH Profiles*2:

A2DP (Advanced Audio Distribution Profile) 1.3
AVRCP (Audio Video Remote Control Profile) 1.3

HFP (Handsfree Profile) 1.6

PBAP (Phone Book Access Profile) 1.1 Corresponding codec: SBC, AAC

*1 The actual range will vary depending on factors such as obstacles between devices, magnetic fields around a microwave oven, static electricity, reception sensitivity, antenna (aerial)'s performance, operating system, software application, etc.

*2 BLUETOOTH standard profiles indicate the purpose of BLUETOOTH communication between devices.

Power amplifier section

Outputs: Speaker outputs Speaker impedance: $4 \Omega - 8 \Omega$

Maximum power output: 55 W \times 4 (at 4 Ω)

General

Power requirements: 12 V DC car battery

(negative ground (earth))
Rated current consumption: 10 A

Dimensions:

Approx. 178 mm \times 100 mm \times 139 mm (7 1/8 in \times 4 in \times 5 1/2 in) (w/h/d)

Mounting dimensions:

Approx. 182 mm \times 111 mm \times 120 mm (7 $^{1/4}$ in \times 4 $^{3/8}$ in \times 4 $^{3/4}$ in) (w/h/d)

Mass: Approx. 1.2 kg (2 lb 11 oz)

Package contents:

Main unit (1)

Parts for installation and connections (1 set)

Remote Commander (1): RM-X170

Microphone (1)

Optional accessories/equipment:

SiriusXM Connect Vehicle Tuner: SXV100,

SXV200, SXV300

Cable for steering wheel remote input: RC-SR1

Ask the dealer for detailed information.

Design and specifications are subject to change without notice.

Copyrights



SiriusXM Connect Vehicle Tuner and Subscription sold separately.

www.siriusxm.com

Sirius, XM and all related marks and logos are trademarks of Sirius XM Radio Inc. All rights reserved.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sony Corporation is under license. Other trademarks and trade names are those of their respective owners.

Windows Media is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.

This product is protected by certain intellectual property rights of Microsoft Corporation. Use or distribution of such technology outside of this product is prohibited without a license from Microsoft or an authorized Microsoft subsidiary.

Apple, iPhone, and Lightning are trademarks of Apple Inc., registered in the U.S. and other countries. Apple CarPlay is a trademark of Apple Inc.

IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Android, Android Auto, Google and Google Play are trademarks of Google LLC.

THIS PRODUCT IS LICENSED UNDER THE MPEG-4 VISUAL PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER FOR DECODING VIDEO IN COMPLIANCE WITH THE MPEG-4 VISUAL STANDARD ("MPEG-4 VIDEO") THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NONCOMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED BY MPEG LA TO PROVIDE MPEG-4 VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE.

ADDITIONAL INFORMATION INCLUDING THAT RELATING TO PROMOTIONAL, INTERNAL AND COMMERCIAL USES AND LICENSING MAY BE OBTAINED FROM MPEG LA. LLC. SEE HTTP://WWW.MPEGLA.COM

THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER TO (i)ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR

(ii)DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE

HTTP://WWW.MPEGLA.COM

THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE AND VC-1 PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER TO DECODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR THE VC-1 STANDARD ("VC-1 VIDEO") THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NONCOMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO AND/OR VC-1 VIDEO, NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE HTTP://WWW.MPEGLA.COM

All other trademarks are trademarks of their respective owners

Troubleshooting

The following checklist will help you remedy problems you may encounter with your unit. Before going through the checklist below, check the connection and operating procedures. For details on using the fuse and removing the unit

from the dashboard, see "Connection/Installation"

If the problem is not solved, visit the support site on the back cover.

General

There is no beep sound.

→ An optional power amplifier is connected and you are not using the built-in amplifier.

The fuse has blown.

The unit makes noise when the position of the ignition is switched.

→ The leads are not matched correctly with the car's accessory power connector.

The display disappears from/does not appear on the monitor.

- → The monitor off function is activated (page 6, 7).
 - Touch anywhere on the display to turn the display back on.

Menu items cannot be selected.

→ Unavailable menu items are displayed in gray.

The USB functions do not work properly.

- → Do not use a USB extension cable as it may cause deterioration of signal quality.
 - Use a shorter USB cable when connecting the USB device, or replace the USB cable with a new one

The unit cannot be operated.

→ Press and hold HOME for more than 10 seconds to restart the unit. For your safety, do not restart the unit while you are driving.

Touch panel operation

The touch panel does not react to your touch correctly.

- → Touch one part of the touch panel at a time. If two or more parts are touched simultaneously, the touch panel will not react correctly.
- → Touch the pressure sensitive panel firmly.
- → The touch panel does not react when touching with a wet fingertip or when water droplets are on the touch panel.
 - Dry your wet fingertips well, or fully wipe water droplets off of the touch panel.

Multi-touch is not recognized.

→ Multi-touch operation is not supported on this unit.

Radio reception

The radio reception is poor. Static noise occurs.

→ Connect the antenna (aerial) firmly.

RDS

PTY displays [PTY not found.].

→ The current station is not an RDS station, or the radio reception is poor.

Picture

There is no picture/picture noise occurs.

- → A connection has not been made correctly.
- → Check the connection between this unit and other equipment and set the input selector of the equipment to the source corresponding to this unit
- → Installation is not correct.
 - Install the unit at an angle of less than 30° in a sturdy part of the car.
- → The parking cord (light green) is not connected to the parking brake switch cord, or the parking brake is not applied.

The picture does not fit in the screen.

→ The aspect ratio is fixed on the playback source.

Sound

There is no sound/sound skips/sound cracks.

- → A connection has not been made correctly.
- → Check the connection between this unit and the connected equipment and set the input selector of the equipment to the source corresponding to this unit.
- → Installation is not correct.
 - Install the unit at an angle of less than 30° in a sturdy part of the car.
- → The unit is in pause/reverse/fast-forward mode.
- → The settings for the outputs are not made correctly.
- → The volume is too low.
- → The ATT function is activated.
- → The format is not supported.
 - Check if the format is supported by this unit (page 19).

Sound is noisy.

→ Keep cords and cables away from each other.

USB playback

Items cannot be played.

- → Reconnect the USB device.
- → The USB port to which the USB device is connected is not appropriate.
 - Connect the USB device to the appropriate USB port that supports the file formats (page 12).

The USB device takes longer to play.

→ The USB device contains large-sized files or files with a complicated tree structure.

Audio files cannot be played.

- → USB devices formatted with file systems other than FAT12, FAT16, FAT32 or exFAT*1 are unsupported.*2
- → The USB port to which the USB device is connected is not appropriate.
 - Connect the USB device to the appropriate USB port that supports the file systems (page 12).
- *1 USB devices formatted with the exFAT file system are available only when connected to the USB1 port.
- *2 This unit supports FAT12, FAT16, FAT32 and exFAT, but some USB device may not support all of these. For details, refer to the operating instructions of each USB device or contact the manufacturer.

Operations cannot be performed.

- → The USB mode of the device is not set to the appropriate mode.
 - Make sure that the USB mode of the device is set to MSC or MTP mode.
- → The USB port to which the USB device is connected is not appropriate.
 - Connect the USB device to the appropriate USB port that supports the features (page 12).

BLUETOOTH function

The other BLUETOOTH device cannot detect this unit.

- → Set [Bluetooth Connection] to [ON] (page 18).
- → While connecting to a BLUETOOTH device, this unit cannot be detected by another device. Terminate the current connection and search for this unit from the other device.
- → Depending on your smartphone or cellular phone, you may need to delete this unit from the history of the connected smartphone or cellular phone then pair them again (page 8).

Connection is not possible.

Check the pairing and connection procedures in the manual of the other device, etc., and perform the operation again.

The name of the detected device does not appear.

→ Depending on the status of the other device, it may not be possible to obtain the name.

There is no ringtone.

→ Raise the volume while receiving a call.

The talker's voice volume is low.

→ Raise the volume during a call.

The other party says that the volume is too low or high.

→ Adjust the [MIC Gain] level (page 15).

Echo or noise occurs during call conversations.

- → Reduce the volume.
- → Set [Speech Quality] to [Mode 1] or [Mode 2]. (page 15).
- → If ambient noise other than the phone call sound is loud, try reducing this noise.
 - Shut the window if road noise is loud.
 - Lower the air conditioner if the air conditioner is loud.

The phone sound quality is poor.

- Phone sound quality depends on reception conditions of the cellular phone.
 - Move your car to a place where you can enhance the cellular phone's signal if the reception is poor.

The volume of the connected BLUETOOTH device is low or high.

- → Volume level will differ depending on the BLUETOOTH device.
 - Reduce the volume level differences between this unit and the BLUETOOTH device (page 12).

The sound skips during audio streaming or the BLUETOOTH connection fails.

- → Reduce the distance between the unit and the BLUETOOTH device.
- → If the BLUETOOTH device is stored in a case which interrupts the signal, remove the case while using the device.
- → Several BLUETOOTH devices or other devices (e.g. ham radio devices) which emit radio waves are used nearby.
 - Turn off the other devices.
 - Increase the distance between the unit and other devices.
- → Playback sound stops momentarily when this unit is connecting to a cellular phone. This is not a malfunction.

The connected BLUETOOTH device cannot be controlled during audio streaming.

Check that the connected BLUETOOTH device supports AVRCP.

Some functions do not work.

→ Check that the connecting device supports the functions in question.

A call is answered unintentionally.

- → The connecting phone is set to start a call automatically.
- → [Auto Answer] of this unit is set to [ON] (page 15).

Pairing failed due to time out.

→ Depending on the connecting device, the time limit for pairing may be short. Try completing the pairing within the time.

Cannot pair.

→ The unit may not be able to pair with a previously paired BLUETOOTH device after initializing the unit if the pairing information of the unit is on the BLUETOOTH device. In this case, delete the pairing information of the unit from the BLUETOOTH device, and then pair them again.

The BLUETOOTH function cannot be operated.

→ Turn the ignition off. Wait for a while, then turn the ignition to the ACC position.

No sound is output from the car speakers during a handsfree call.

→ If the sound is output from the cellular phone, set the cellular phone to output the sound from the car speakers.

SiriusXM Connect Vehicle Tuner

A mature channel is not blocked although parental control setting has been made.

- → If you tune to a mature channel, the passcode display will appear. Once you have entered the passcode, you will have unblocked parental control for all channels until the unit is powered down or you turn parental control back on.
 - Set [Parental Control] to [Locked] in the SXM option (***) again (page 11).

Apple CarPlay

The Apple CarPlay icon does not appear on the HOME screen.

- → Your iPhone is not compatible with Apple CarPlay.
- Refer to the compatibility list on the support site on the back cover.
- → Disconnect your iPhone from the USB1 port and reconnect it again.
- → The USB port to which your iPhone is connected is not appropriate.
 - Connect your iPhone to the USB1 port.
- → Apple CarPlay may not be available in your country or region.
- → Make sure a certified Lightning cable is used to connect your iPhone and the unit.

Android Auto

The Android Auto icon does not appear on the

- → Check your Android phone and accept the disclaimers and permission requests required to use Android Auto on your Android phone.
- → There is no Android Auto application installed on your Android phone.
 - Download and install the Android Auto application onto your Android phone.
- Your Android phone is not compatible with Android Auto.
 - Android phone with Android 5.0 or higher is required. Refer to the compatibility list on the support site on the back cover.
- Disconnect your Android phone from the USB1 port and reconnect it again.
- → The USB port to which your Android phone is connected is not appropriate.
- Connect your Android phone to the USB1 port.
- Android Auto may not be available in your country or region.

Messages

General

Cannot play this content.

- → The currently selected content cannot be played back, or skipped to the next one.
 - The content is not in a supported file format.
 Check supported file formats (page 19).

Device no response

- The unit does not recognize the connected USB device.
 - Reconnect the USB device.
 - Check that the USB device is supported by the unit.

No Playable Data

- → The USB device has no playable data.
 - Load music data/files into the USB device.

Overcurrent caution on USB.

- → The USB device is overloaded.
 - Disconnect the USB device.
 - Indicates that the USB device is out of order, or an unsupported device is connected.

USB device not supported

→ For details on the compatibility of your USB device, visit the support site on the back cover.

USB hub not supported

→ USB hubs are not supported on this unit.

BLUETOOTH

Bluetooth device is not found.

- → The unit cannot detect a connectable BLUETOOTH device.
 - Check the BLUETOOTH setting of the connecting device.
- No device is in the list of registered BLUETOOTH devices.
 - Perform pairing with a BLUETOOTH device (page 8).

Handsfree device is not available.

- → A cellular phone is not connected.
 - Connect a cellular phone (page 9).

SiriusXM Connect Vehicle Tuner

Channel Locked

Please Enter the Lock Code

→ The channel that you have requested is Locked by the radio Parental Control feature. See "To set a parental control" (page 11) for more information on the Parental Control feature and how to access locked channels.

Channel Not Available

- → The channel that you have requested is not a valid SiriusXM channel or the channel that you were listening to is no longer available.
- → You may also see this message briefly when first connecting a new SiriusXM Connect Vehicle Tuner.

Visit www.siriusxm.com in the USA or www.siriusxm.ca in Canada for SiriusXM channel lineup information.

Channel Not Subscribed Call SiriusXM to Subscribe

→ The channel that you have requested is not included in your SiriusXM subscription package or the channel that you were listening to is no longer included in your SiriusXM subscription package.

If you have questions about your subscription package or would like to subscribe to this channel, please contact SiriusXM.

In the USA, visit www.siriusxm.com or call 1-866-635-2349.

In Canada, visit www.siriusxm.ca or call 1-877-438-9677.

Check Antenna

- → The radio has detected a fault with the SiriusXM antenna (aerial).
- → The antenna (aerial) cable may be either disconnected or damaged.
 - Verify that the antenna (aerial) cable is connected to the SiriusXM Connect Vehicle Tuner.
 - Inspect the antenna (aerial) cable for damage and kinks.
 - Replace the antenna (aerial) if the cable is damaged. SiriusXM products are available at your local car audio retailer or online at www.shop.siriusxm.com

Check SXM tuner.

- → The radio is having difficulty communicating with the SiriusXM Connect Vehicle Tuner.
- → The tuner may be disconnected or damaged.
- Verify that the SiriusXM Connect Vehicle Tuner cable is securely connected to the radio.

Incorrect Pass Code entered

- → Passcode input failed.
 - Check that the passcode has been entered correctly.
 - If you forget your passcode, perform [SXM Reset] in [General] (page 17).
 Note that performing [SXM Reset] will initialize all the SiriusXM settings and stored contents in the SiriusXM Connect Vehicle Tuner.

No Signal

- SiriusXM Connect Vehicle Tuner is having difficulty receiving the SiriusXM satellite signal.
 - Verify that your vehicle is outdoors with a clear view of the sky.
 - Verify that the SiriusXM magnetic mount antenna (aerial) is mounted on a metal surface on the outside of the vehicle.
 - Move the SiriusXM antenna (aerial) away from any obstructions.
 - Inspect the antenna (aerial) cable for damage and kinks.
 - Consult the SiriusXM Connect Vehicle Tuner installation manual for more information on antenna (aerial) installation.
 - Replace the antenna (aerial) if the cable is damaged. SiriusXM products are available at your local car audio retailer or online at www.shop.siriusxm.com

Subscription Updated Press Enter to Continue

- → The radio has detected a change in your SiriusXM subscription status.
 - Press Enter to clear the message.
 If you have questions about your subscription, please contact SiriusXM.
 In the LISA, vicit www.siriusxm.com.or.call

In the USA, visit www.siriusxm.com or call 1-866-635-2349.

In Canada, visit www.siriusxm.ca or call 1-877-438-9677.

If these solutions do not help improve the situation, consult your nearest Sony dealer.

Connection/Installation

Cautions

- Do not install this unit in a car that has no ACC position. The display of the unit does not turn off even after turning the ignition off, and this causes battery drain.
- Run all ground (earth) leads to a common ground (earth) point.
- Do not get the leads trapped under a screw or caught in moving parts (e.g., seat railing).
- Before making connections, turn the car ignition off to avoid short circuits.
- Connect the yellow and red power supply leads only after all other leads have been connected.
- Be sure to insulate any loose unconnected leads with electrical tape for safety.

Precautions

- Choose the installation location carefully so that the unit will not interfere with normal driving operations.
- Avoid installing the unit in areas subject to dust, dirt, excessive vibration, or high temperature, such as in direct sunlight or near heater ducts.
- Use only the supplied mounting hardware for a safe and secure installation.


Note on the power supply lead (yellow)

When connecting this unit in combination with other stereo components, the amperage rating of the car circuit to which the unit is connected must be higher than the sum of each component's fuse amperage rating.

Mounting angle adjustment


Adjust the mounting angle to less than 30°.

Parts List for Installation



This parts list does not include all the package contents.

Connection



- *1 Not supplied
- *2 Speaker impedance: $4 \Omega 8 \Omega \times 4$
- *3 RCA pin cord (not supplied)
- *4 Depending on the type of car, use an adaptor for a wired remote control (not supplied). For details on using the wired remote control, see "Using the wired remote control" (page 30).
- *5 Depending on the type of car, use an adaptor (not supplied) if the antenna (aerial) connector does not fit.
- *6 Whether in use or not, route the microphone input cord so it does not interfere with driving operations. Secure the cord with a clamp, etc., if it is installed around your feet
- *7 For details on installing the microphone, see "Installing the microphone" (page 29).
- *8 Do not use a USB extension cable.
- *9 For more information on how to install the SiriusXM Connect Vehicle tuner, consult the installation guide included with the tuner.

Making connections

1 To a common ground (earth) point

First connect the black ground (earth) lead then connect the yellow and red power supply leads.

2 To the +12 V power terminal which is energized at all times

Be sure to first connect the black ground (earth) lead to a common ground (earth) point.

To the +12 V power terminal which is energized when the ignition switch is set to the accessory position

Be sure to first connect the black ground (earth) lead to a common ground (earth) point.

To the power antenna (aerial) control lead or the power supply lead of the antenna (aerial) booster

It is not necessary to connect this lead if there is no power antenna (aerial) or antenna (aerial) booster, or with a manually-operated telescopic antenna (aerial).

To AMP REMOTE IN of an optional power amplifier

This connection is only for amplifiers and a power antenna (aerial). Connecting any other system may damage the unit.

Note


It will take about 10 seconds to shut down the output of REM OUT after the unit is turned off.

6 To a car's illumination signal

Be sure to first connect the black ground (earth) lead to a common ground (earth) point.

6 To the parking brake switch cord

The mounting position of the parking brake switch cord depends on your car.
Be sure to connect the parking brake lead (light green) of the power supply connection cable ① to the parking brake switch cord.



 To the +12 V power terminal of the car's rear lamp lead (only when connecting the rear view camera)

Memory hold connection


When the yellow power supply lead is connected, power will always be supplied to the memory circuit even when the ignition switch is turned off.

Speaker connection

- Before connecting the speakers, turn the unit off.
- Use speakers with an impedance of 4 Ω to 8 Ω and with adequate power handling capacities to avoid damage.

Installing the microphone

To capture your voice during handsfree calling, you need to install the microphone ③.



Cautions

- It is extremely dangerous if the cord becomes wound around the steering column or gearstick.
 Be sure to keep it and other parts from interfering with your driving operations.
- If airbags or any other shock-absorbing equipment are in your car, contact the store where you purchased this unit or the car dealer before installation.

Note

Before attaching the double-sided tape (4), clean the surface of the dashboard with a dry cloth.

Using the wired remote control

When using the steering wheel remote control

wheel remote control becomes available.

Installation of the connection cable RC-SR1 (not supplied) is required before use.

1 To enable the steering wheel remote control, select [General] → [Steering Control] → [Custom] → [] to make the registration (page 17). When the registration is complete, the steering

Notes on installing the connection cable RC-SR1 (not supplied)

- Refer to the support site on the back cover for details then connect each lead properly to the appropriate leads.
 Making an improper connection may damage the unit.
- Consulting the dealer or an experienced technician for help is recommended.

When using the wired remote control

1 To enable the wired remote control, set [Steering Control] in [General] to [Preset] (page 17).

Using the rear view camera

Installation of the rear view camera (not supplied) is required before use.


The picture from a rear view camera connected to the CAMERA IN terminal is displayed when:

- the back lamp of your car lights up (or the shift lever is set to the R (reverse) position).
- you press HOME, touch [Rear Camera].


Installation

Mounting the unit in a Japanese car

You may not be able to install this unit in some Japanese cars. In such a case, consult your Sony dealer.



When mounting this unit to the preinstalled brackets of your car, use the supplied screws ② in the appropriate screw holes based on your car: T for TOYOTA and N for NISSAN.



Note

To prevent a malfunction, install only with the supplied screws ②.

Fuse replacement

When replacing the fuse, be sure to use one matching the amperage rating stated on the original fuse. If the fuse blows, check the power connection and replace the fuse. If the fuse blows again after replacement, there may be an internal malfunction. In such a case, consult your nearest Sony dealer.

Support site

If you have any questions or for the latest support information on this product, please visit the web site helow:

Site d'assistance

Si vous avez des questions ou si vous técnico en línea souhaitez consulter les toutes dernières informations techniques sur ce produit, rendez-vous sur le site Web suivant:

Sitio Web de soporte

Para resolver cualquier duda u obtener la información más reciente sobre el soporte técnico de este producto. visite el siguiente sitio Web:

http://esupport.sony.com/

If you have any questions/problems regarding this product, try the following:

- Read Troubleshooting in these Operating Instructions.
- 2 Please contact (U.S.A. only); Call 1-800-222-7669 URL http://www.SONY.com

Smartphone app

Support by Sony app - Find information and get notification about your product:

App. de smartphone

Support by Sony app - Trouvez des infos et recevez des notifications au sujet de votre produit :

Aplicación para Smartphone

Aplicación Support by Sony - Busque información y obtenga notificaciones acerca de su producto:





- √ News & Alerts / Actus & Alertes / Noticias y Alertas
- √ Software updates / Mises à jour / Actualizaciones de software
- √ Tutorials / Didacticiels / Tutoriales
- √ Tips & Tricks / Conseils & Astuces / Consejos y Trucos

https://sony.net/SBS







androidauto



XAV-AX5000

7" Media Receiver with Bluetooth®

7" touchscreen media receiver with voice-controlled Apple CarPlay¹ and Android Auto². Bluetooth³ and dual USB connections provide various ways to connect hands free.



- · Voice control with Apple CarPlay and Android Auto
- Bezel-less panel for a seamless touchscreen display
- Ergonomic aluminum key panel for easy operation
- Dual USB ports let you connect a smartphone and USB simultaneously
- Create virtual speakers on your dashboard with the Dynamic Stage Organizer

Apple CarPlay makes driving smarter¹

Use all your essential iPhone functions on the road with Apple CarPlay. Just plug-in your phone to get started. Tap the icons to take calls, check voicemails and text messages, bring up maps, or even talk to Siri. And of course, listen to your favorite songs using iTunes, Apple Music or apps. You can dictate text messages, control music playback or get directions, without ever taking your eyes off the road.

Android Auto™ gives you all the help you need2

Journeys are easier and safer with help from Android Auto. Plug-in your phone to get traffic information, lane guidance, and real-time navigation assistance from Google maps. You can even send text messages, take calls or check your voicemail through the simple interface. Android Auto also includes best-in-class voice-recognition technology, so you can get directions, send messages, make calls, and control music while keeping your hands safely on the wheel.

See and control everything on a flush 7" touchscreen

Bring up maps, sort through playlists, and make phone calls – all with just a quick tap on the touch controls. The ultra-slim 7" display uses a bezel-less panel, for a smooth fit on the dashboard that blends seamlessly with your car interior.

Quick-access key panel

Enjoy quick and easy operation on the road. Keys along the bottom of the receiver give you instant access to basic features such as volume, source, sound settings and voice control.

Easy installation with a compact rear chassis

Despite its double-DIN display, the rear chassis is far smaller than conventional double-DIN units. This makes for much easier installation, and leaves plenty of room for cabling and other accessories in the space behind the display.

Dual USB ports

Enjoy all the greatest hits from your music library while your phone handles directions. Thanks to dual USB ports, you can connect your smartphone and USB media device at the same time.

Three pre-outs let you expand your sound system

Looking to build your own in-car sound system? Three pre-outs give you countless possibilities for expanding your setup. Plug in your desired amplifiers and sub-woofers to customize your sound.

Rear camera ready for easy backing and parking

If you've got a rear camera installed, you can use it to help you park. Whenever you place the vehicle in reverse or tap the rear camera icon or put your vehicle in reverse, the video feed instantly comes up on the screen. Customizable guidelines help you to back in smoothly and safely.

BLUETOOTH® wireless technology³

Make hands-free calls and stream wireless audio from your smartphone, with Bluetooth®3

4 x 55W amplification for clear, powerful sound

The Dynamic Reality Amp 2 gives you 4 x 55W of power, so you can play music as loudly or softly as you like. The amp has 47% less internal resistance than conventional units, for increased output and clear, natural sound at any volume.

Dynamic Stage Organizer creates virtual speakers on your dashboard



Sound waves are directional, especially in the higher frequencies – so if your speakers are positioned low in your doors, high frequency sounds are often lost, reducing clarity and instrument separation. Dynamic Stage Organizer uses digital signal processing to lift the sound, improving stereo positioning so music sounds like it's coming from right in front of you.

FLAC compatible

FLAC compatibility lets you play lossless audio files, so you can enjoy every detail of the music.

Sirius XM Radio ready⁴

Connect your Sirius XM Radio satellite tuner (not supplied) to enjoy commercial-free music, sports, news, and entertainment.⁴

Play video anywhere

Whenever your car isn't moving, enjoy your favorite movies and TV shows with the built-in DVD player.

10-band equalizer lets you customize your sound

Hear your music the way you want to, with the built-in graphic equalizer. Cut and boost ten different frequencies for unlimited sound sculpting options.

Bring out the bass

Hit the EXTRA BASS button for deep, punchy sound at any volume. Switch between two settings for different intensities of bass boost.

Steering wheel control ready input⁵

This receiver is compatible with aftermarket remote control adapters designed to utilize the vehicles existing, primary radio controls directly from the steering wheel. The 1/8" rear panel mounted remote input jack allows for simple connectivity.⁵

Switch volume and tracks from the wheel⁵

Easily set up basic audio controls from your steering wheel without a signal converter, on compatible vehicles.5

External hands free mic supplied

The included external hands-free microphone and integrated echo and noise canceling circuitry assure your conversations are clear.

Convenient wireless remote supplied

Control your receiver with the included wireless card remote (RM-X170).

Specifications

Bluetooth Feature			
Call Volume Level Control	Yes		
Connection Status (maximum #)	(1HFP/PBAP+1Audio)		
External microphone	Supplied		
MIC GAIN Adjustment	Low/Mid/High		
Phonebook Access via PBAP	Yes		
RF ON/OFF	Yes		
Ring volume level control	Yes		
Speed dial	Yes (6 memories)		
TEL out channel	Front		
# of records connected	9		
Alphabetical Phonebook Sorting (PBAP)	Yes		
Battery remainder indication	Yes		

Echo canceller	Yes		
Internal ringtone	1(2016 Sony Mobile Ringtone)		
Last dialed call	Yes(select from the dialed call history)		
Noise canceller	Yes		
Phonebook code	UTF8		
recent calls (#of)	Yes		
Signal strength indication	Yes		
Bluetooth Audio Feature			

Bluetooth Audio Feature			
Audio Codec	SBC/ AAC		
Audio Level Adjustment	Yes(-8dB to +18dB)		
CUE/REV	Yes		
Group (Folder) +/-	Yes		
Meta Data Indication	Yes		
Pause	Yes		
Repeat Control (Audio Device side)	Yes		

SONY

Shuffle Control		Feature & Device	· / Expandability
(Audio Device side)	Yes	Bluetooth	Yes
TRACK +/-	Yes	METRA Ready	Yes
	e & Device / BT Spec.	Pre Out	3 Pre Out
Version	Version 3.0	Rear Out	Yes
	e & Device / Display Panel(MDP and AVC)	Rear View	Yes
Dimmer Adjust	Yes	Camera Input Sub Out	Yes
Dimmer Area	Display Monitor and Key	USB	Yes (Rear x2)
Monitor off mode	Yes	-	
Bluetooth Feature	e & Device / Monitor(AVC)	Feature & Device Screen Size (Inch)	7inch (6.95inch)
Brightness	500cd/m2	Touch Panel	Yes / Capacitive (Not Multi Touch Compatible)
Color System	NTSC/PAL		e / General Feature
Color System Auto switch	Yes	Firmware upgradability	Yes
Contrast Ratio	600	Gesture	
Dimmer	Yes	Command	Yes
Dimmer Method	Auto/Manual select	Selectable	Yes
LCD Type	TFT Active Matrix	Background Color	
Resolution (DOT)	800 × 480	Tag Indication	Yes (USB2, USB1: Except Flac and WAV)
Response Time	00/00		e / Smartphone Linkage
(black-white/ white-black)	20/20ms	Android Auto	Yes
Screen Diagonal	6.95 inch	Apple CarPlay	Yes
(inch/mm) Screen Mode	Yes: Type1 to 4	Voice Command (Smartphone Function) Activate	Yes (only CPAA)
Screen Size (WxH	154.6 v. 91.6(mm)	Feature & Device	: / Sound
mm)	156.6 x 81.6(mm)	DSO	Yes
Viewing Angle (Contrast Ratio	70/70/60/60 (L/R/U/D)	EXTRA BASS	Yes(Off/1/2)
10:1)	70,70,000,00 (2,11,0,12)	Graphic Equalizer	10Band Graphic Equalizer
Bluetooth Feature	e & Device / Multi Language	Output Power	55W
Caution	English/Spanish/French/Germany/Italian/Russian/ Portuguese/Thai/Simplified Chinese/Traditional Chinese/	Feature & Device	/ Tuner Feature FM18/AM12
	Korean/Arabic	RDS / EON	Yes (RBDS)
D3 Tag	English/Spanish/French/Germany/Italian/Russian/ Portuguese/Thai/Simplified Chinese/Traditional Chinese/		Device Control Feature
	Korean/Arabic	Pause	Yes
Menu	English/Spanish/French/Germany/Italian/Russian/ Portuguese/Thai/Simplified Chinese/Traditional Chinese/	Repeat	Track/ Folder/ Drive
THO TO	Korean/Arabic	Resume Play	Yes
Menu/Caution	English	Shuffle	Off/ Folder/ Device
Initial Bluetooth Feature	e & Device / Profile	USB Control Feat	
A2DP	Yes (1.3)	CUE/REV	Yes (Video: lock search)
AVRCP	Yes (1.3)	ID3 Tag Indication	
HFP	Yes (1.6)	(Version, Title/ Artist/Album)	Yes
PBAP	Yes (1.1)	List	Yes
	e & Device / Panel Design	Max Layer#/	
Key illumination	Yes (White)	Folder#/File#	8/1000/20000
Panel Surface		Pause	Yes
Finish Color	Black	PICTURE EQ	Yes
Bluetooth Feature	e & Device / Other features	Repeat	Yes
Device Name	XAV-AX5000	Repeat/Shuffle	Yes

SONY

Repeat Initial	All	Accessibility	Closed Caption / TTS: No support
Shuffle	Yes	ANT connector	JASO
USB Feature & De	vice / USB Capability	C/O	Yes
connection-		Connector type	16P
enabled device list	WEB Support	Maximum output power (40hms,	55W
File System	USB1: exFAT, FAT12/16/32, USB2: FAT12/16/32	1kHz, 16V)(W)	3500
USB Mass Storage Device	Yes	POP	Yes (CPAA)
		Power Connector	Yes
USB Media Transfer Protocol	USB1: No, USB2: Yes	Speaker impedance	4-8Ω
USB Mass Strage [Device Control Feature	(ohms)	
Audio Codec	USB1:PCM/MP3/WMA/AAC/FLAC, USB2:MP3/WMA/ FLAC	Preout output level (V)	2Vrms
Audio Playable	USB1: .wav/.mp3/.wma/.m4a/.flac, USB2:.mp3/.wma/.	Specifications ch	art / Tuner
File Extension MTP	flac USB1: No, USB2: Yes	FM: Tuning range(MHz)	87.5-107.9
Video Codec	Only USB1:MPEG4-SP/AVC(H.264 Baseline)/WMV/MKV/XviD	FM (Tuning range(MHz)/	v
Video Playable File Extension	Only USB1: .mp4/.wmv/.mkv	step(kHz)/de- emphasis(mus)) 87.5-107.9/200/75	Yes
USB Specification		MW: Tuning	530-1710
Version	USB1: USB2.0 (High speed), USB2: USB2.0 (Full speed)	range(kHz)	000-1710
USB Feature & De	vice / Other features	MW(Tuning range(kHz)/	Yes
Power Supply	Yes (USB1:max 1.5A(CDP), USB2:max500mA)	step(kHz)) 530-	
Others / Connect	tivity List	1710/10	
3rd Party	Yes	Weights and Med	asurements
Navigation	3rd Party Car Infomation Adapter: Yes	Dimensions (Approx.)	178×100×139 mm
Others / Safety St	andard	Weight (Approx.)	1.2 kg
Canada IC	Yes	Accessories	
FCC	Yes		Warranty card
Specifications ch	art / General	Supplied Accessories	Ant connector (JASO)

- 1. Apple CarPlay is compatible with iPhone 5 model and later with at least IOS 7.1. Some features, applications, and services are not available in all areas.
- 2. Android Auto™ is compatible with Android phones running Android 5.0 (Lollipop) or later. Android Auto™ may not be available on all devices and is not available in all countries or regions.
- 3. Interoperability and compatibility among Bluetooth® devices vary
- 4. Requires tuner and subscription, sold separately.
- 5. Compatibility varies as not all vehicles are compatible; please consult with each interface manufacturer for details.

©2017 Sony Electronics Inc. All rights reserved. Reproduction in whole or in part without written permission is prohibited. Sony and the Sony logo are registered trademarks of Sony Corporation. Bluetooth is a trademark of Bluetooth SIG, Inc. Android, Android Auto and its logos are registered trademarks of Google Inc. Apple, Apple CarPlay, Siri and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. All other trademarks are trademarks of their respective owners. Features and specifications are subject to change without notice. Updated: February 9, 2018



LIMITED WARRANTY

Car Audio

U.S. and Canada only - 1 year

Sony Electronics Inc. solely for purchases made in the United States and Sony of Canada Ltd. solely for purchases made in Canada (collectively "Sony") warrants this product against defects in material or workmanship for the original owner and any subsequent end user owner(s) ("You" or "Your") for the time period set forth above as set forth herein. Pursuant to this Limited Warranty, Sony will, at its option, (i) repair the product using new or refurbished parts or (ii) replace the product with a new or recertified/refurbished product of the same (or similar) model. For purposes of this Limited Warranty, "recertified" or "refurbished" means a product or part that has been returned to its original specifications. In the event of a defect, these are Your exclusive remedies. Sony does not warrant that the operation of the product will be uninterrupted or error-free.

Term: For the time period set forth above from the original date of purchase of the product when purchased directly from Sony or Sony authorized dealer (To determine if a dealer is in the Sony authorized dealer network, please visit US: www.sony.com/retailers; Canada: https://dealerlocator.sony.ca/locator; or contact Sony directly), Sony will, at its option, repair or replace with a new, recertified or refurbished product or part, any product or part determined to be defective.

This Limited Warranty covers only the hardware components packaged with the product. It does not cover separate accessories, technical assistance for hardware or software usage and it does not cover any software products whether or not contained in the product, and other included content; any such software or other included content is provided "AS IS" unless expressly provided for in any enclosed software Limited Warranty or End User License Agreement. Please refer to the End User License Agreement(s) included with the product for Your rights and obligations with respect to the software or other included content. If You purchased an extended service plan, please refer to the service plan for the coverage, duration and terms of service. Extended service plans are not governed by this Limited Warranty

To obtain warranty service, You must deliver the product, in either its original packaging or packaging affording an equal degree of protection to a Sony authorized service center together with a dated purchase receipt in order to obtain warranty service. Sony cannot guarantee that it will be able to repair any product under this warranty or make a product exchange without risk to or loss of software or data. It is Your responsibility to remove or backup any removable media or parts, data, software or other materials You may have stored or preserved on Your product. It is likely that any media or parts, data, software, or other materials (like pictures, music, videos, etc.) will be lost or reformatted during service and Sony will not be responsible for any such damage or loss. Contact the following for specific instructions on how to obtain warranty service for Your product:

For purchases made in the UNITED STATES:

Visit Sony's Website: www.sony.com/support
Or call the Customer Experience Center: 1-800-222-SONY (7669)
To register Your product or for contact information to purchase accessories or parts go to Sony's Website

For purchases made in CANADA:

Visit Sony's Website: www.sony.ca/support

Or call the Customer Experience Center: 1-877-899-SONY (7669)
To register Your product or for contact information to purchase accessories or parts go to Sony's Website

On-site service for televisions of certain dimensions may be available to a customer living within a 50km radius of an authorized Sony service facility, provided the residence can be accessed by an on-road service vehicle.

Repair/Replacement Warranty: This Limited Warranty shall apply to any repair, replacement part or replacement, recertified or refurbished product for the remainder of the original Limited Warranty period or for ninety (90) days, whichever is longer. Any parts or product replaced under this Limited Warranty will become the property of Sony. Any replacement, recertified or refurbished product provided under this Limited Warranty may, at Sony's option, vary in color and/or cosmetic design from the original product and may not include any original engraving or similar customization/personalization.

Sony is not responsible for, and this Limited Warranty does not cover, any damage arising from a failure to operate the product within its intended uses, or otherwise follow the owner's manual and safety instructions relating to the product's use and installation. This Limited Warranty only covers product issues caused by defects in material or workmanship during ordinary consumer use. This Limited Warranty does not cover products purchased from sources other than Sony or a Sony authorized dealer (including non-authorized online auctions), or issues due to: (i) outdoor exposure and other acts of nature; (ii) power surges; (iii) accidental damage; (ivi) abuse; (v) limitations of technology; (vi) cosmetic damage; (vii) contact with liquid, heat, humidity or perspiration, sand, smoke, or foreign materials; (viii) use of parts or supplies not sold or authorized by Sony; (iv) servicing not authorized or performed by Sony or a Sony authorized service center; (x) computer or internet viruses, bugs, worms, or Trojan Horses; (xi) malfunctions due to peripherals/accessories; (xii) modifications of or to any part of the product, including "rooting" or other modifications to control the behavior of the product or any factory installed operating system; (xiii) consumable parts such as batteries; or (xiv) any product where the factory-applied serial number has been altered or removed from the product. Further, to the extent this product incorporates use of a display, please note that a display contains hundreds of thousands of individual pixels, and displays typically contain a small number of pixels that do not function properly. This Limited Warranty does not cover up to .01% pixel outages (small dot picture elements that are dark or incorrectly illuminated).

This Limited Warranty does not cover Sony products sold "AS IS" or "WITH ALL FAULTS" or consumables (such as fuses or disposable batteries). Sony will not replace missing components from any package purchased "Open Box" or "AS IS". This Limited Warranty is valid only in the United States and Canada (as applicable).

LIMITATION ON DAMAGES: SONY SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY OR CONDITION ON THIS PRODUCT. NOR SHALL RECOVERY OF ANY KIND AGAINST SONY BE GREATER THAN THE ORIGINAL PURCHASE PRICE OF THE PRODUCT FROM SONY OR AN AUTHORIZED SONY DEALER.

DURATION OF IMPLIED WARRANTIES OR CONDITIONS: EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTIBILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS LIMITED WARRANTY.

Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to You. This Limited Warranty gives You specific legal rights and You may have other rights which vary from jurisdiction to jurisdiction.

For purchases made in the U.S.: Read the following Dispute Resolution/Arbitration provision carefully. It details Your rights and instructions should a dispute related to the product arise.

What Happens If We Have A Dispute: Should a dispute or claim arise related to the product, Your purchase and/or use of the product, the terms of this Limited Warranty, or any service provided under the terms of this Limited Warranty (including any repair or replacement) ("Dispute"), You and Sony agree that the Dispute shall be resolved exclusively through binding arbitration. YOU UNDERSTAND AND ACKNOWLEDGE THAT BY AGREEING TO ARBITRATION, YOU ARE GIVING UP THE RIGHT TO LITIGATE (OR PARTICIPATE IN AS A PARTY OR CLASS MEMBER) IN ANY DISPUTES IN COURT. You also agree that ANY DISPUTE RESOLUTION PROCEEDING WILL ONLY CONSIDER YOUR INDIVIDUAL CLAIMS, AND BOTH PARTIES AGREE NOT TO HAVE ANY DISPUTE HEARD AS A CLASS ACTION, REPRESENTATIVE ACTION, CONSOLIDATED ACTION, OR PRIVATE ATTORNEY GENERAL ACTION. Despite the above, You have the right to litigate any Dispute on an individual basis in small claims court or other similar court of limited jurisdiction, to the extent the amount at issue does not exceed \$15,000, and as long as such court has proper jurisdiction and all other requirements (including the amount in controversy) are satisfied.

Arbitration Instructions. To begin Arbitration, either You or Sony must make a written demand to the other for arbitration. The Arbitration will take place before a single arbitrator. The arbitration will be administered in keeping with the Expedited Procedures of the Commercial Arbitration Rules and the Supplementary Proceedings for Consumer-Related disputes ("Rules") of the American Arbitration Association ("AAA"), when applicable and in effect when the claim is filed. You may get a copy of AAA's Rules by contacting AAA at (800) 778-7879 or visiting www.adr.org. The filing fees to begin and carry out arbitration will be shared between You and Sony, but in no event shall Your fees ever exceed the amount allowable by the special rules for Consumers Disputes provided for by AAA, at which point Sony will cover all additional administrative fees and expenses. This does not prohibit the Arbitrator from giving the winning party their fees and expenses of the arbitration when appropriate pursuant to the Rules. Unless You and Sony agree differently, the arbitration will take place in the county and state where You live, and applicable federal or state law shall govern the substance of any Dispute during the arbitration. However, the Federal Arbitration Act, 9 U.S.C. § 1, et seq., will govern the arbitration Act.

Opt-Out Instructions. IF YOU DO NOT WISH TO BE BOUND BY THE BINDING ARBITRATION PROVISION, THEN: (1) You must notify Sony in writing within 30 days of the date that You purchased the product; (2) Your written notification must be mailed to Sony Electronics Inc., 16535 Via Esprillo, MZ 1105, San Diego CA 92127, Attn: Legal Department; AND (3) Your written notification must include (a) Your NAME, (b) Your ADDRESS, (c) the DATE You purchased the product, and (d) a clear statement that "YOU DO NOT WISH TO RESOLVE DISPUTES WITH ANY SONY ELECTRONICS ENTITY THROUGH ARBITRATION AND/OR BE BOUND BY THE CLASS ACTION WAIVER."

Opting out of this dispute resolution procedure will not affect the coverage of the Limited Warranty in any way, and You will continue to enjoy the benefits of the Limited Warranty.